

SUPTRACTOR

For 9.3 inch Nighthawk
222 mm spindle-to-mount-centre
237.4 mm spindle to pivot
Baerwald geometry

STEP 1

Spindle-to-pivot distance:

- push protractor hole onto spindle
- rotate protractor point to pivot point
- correct discrepancy (see manual) or...
- calculate new effective length

STEP 2

Pivot-to-stylus distance:

- place protractor point at pivot point
- lower stylus onto curves
- adjust cartridge for correct length

STEP 3

Cartridge offset angle:

- push protractor hole onto spindle
- rotate so stylus sits on null point
- align cartridge with grid
- repeat steps 2 and 3 until dizzy

